

Technaxx® * User Manual

Dual Camera Outdoor TX-328

Before using the appliance for the first time, please read the instructions for use and safety information carefully.



This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capacities, or by persons lacking in experience or knowledge, unless they are supervised or instructed on the use of this device by a person responsible for their safety. Children should be supervised to ensure they do not play with this device.

Keep this user manual for future reference or product sharing carefully. Do the same with the original accessories for this product. In case of warranty, please contact the dealer or the store where you bought this product.

Enjoy your product. * Share your experience and opinion on one of the well-known internet portals.

Specifications are subject to change without notice - please be sure to use the latest manual available on the manufacturer's website.

Table of Contents

Hints	2	Wall mount	12
Safety instructions	3	Security Premium App.....	14
Warnings	3	Registration	14
Notes on data protection	3	Forget Password	14
Disclaimer.....	4	How to add a device.....	15
Features	5	Add Device	15
Product overview.....	6	How to navigate in the App	17
Camera	6	Device	17
General information.....	7	Live view	17
Power connection.....	7	Playback	23
MicroSD card	7	Me (personal area).....	25
IR LED.....	7	PC Software Windows (& MAC).....	27
White LED	7	Installation	27
Status LED	8	Login and add device	27
RESET Button.....	8	Open live view.....	28
Quick operation guide	9	Playback recordings.....	29
For STANDALONE USE		Troubleshooting.....	30
Fehler! Textmarke nicht		FAQs	32
definiert.		Technical Specifications.....	33
Preparation.....	9	Support.....	34
Get App and add camera	9	Care and maintenance	34
Mounting.....	12	Declaration of Conformity.....	34
Alignment	12	Disposal.....	35

Hints

● Only use the product for purposes due to its intended function ● Do not damage the product. Following cases may damage the product: Incorrect voltage, accidents (including liquid or moisture), misuse or abuse of the product, faulty or improper installation, mains supply problems including power spikes or lightning damage, infestation by insects, tampering or modification of the product by persons other than authorized service personnel, exposure to abnormally corrosive materials, insertion of foreign objects into the unit, used with accessories not preapproved. ● Refer to and heed all warnings and precautions in the user manual.

Safety instructions

- The product is intended for the recording of digital photos and videos. It is intended for use by private individuals.
- Never touch the product with wet or damp hands.
- The product can only be operated with the voltage described on the interior panel.
- Do not place the product on an unstable surface. The unit could be damaged or persons could be injured. Any attachments should be made only in accordance with the manufacturer's instructions or obtained from the manufacturer.
- The cable is sheathed and insulates the current. Do not place any objects on the cable, as this could cause the protective function to be lost. Avoid placing excessive stress on the cable, especially at sockets and plugs.
- If you want to pull the plug out of the socket, always pull on the plug and not on the cable. The cable could otherwise break.
- Do not overload wall outlets, extension cords, or other wiring as this may result in fire or electric shock.
- Do not insert any objects into the openings of the unit, as current flows in some places and contact may cause fire or electric shock.
- Unplug the power cord from the power outlet for cleaning.
- Do not use liquid cleaners or cleaning sprays. The product may only be cleaned with a damp cloth.
- Do not connect any additional devices that are not recommended by the manufacturer.
- Do not use the product in direct sunlight or places where the temperature may exceed 45°C for a long time.

Warnings

- Do not disassemble the product, it may result in short-circuit or damage.
- Do not modify, repair or remove without professional guidance.
- Do not use corrosive or volatile liquid for cleaning.
- Do not drop or shake the device, it may break internal circuit boards or mechanics.
- Keep the device away from little children.

Notes on data protection

- Personal rights: When setting up the camera, be sure to respect the personal rights of the people around you. Under no circumstances may you set up the camera in such a way that people who happen to enter the recording area of the camera are recorded in such a way that they can be identified in any way! This also applies to the recognizable recording of vehicle license plates.

- Do not monitor public areas: Observe all national laws and regulations regarding the legality of recording in public areas (streets, sidewalks, parking lots, etc.) by private persons. Refrain from using the camera in such an environment that is in defiance of the law.

- No workplace monitoring: Observe all national laws and regulations regarding the legality of recording at the workplace by an individual. Refrain from using the camera in the workplace in a way that is in defiance of the law. Under no circumstances may you use the camera to monitor your use the camera for employee monitoring! Surveillance in the workplace is subject to particularly strict conditions in Germany.

- Delete recordings: Photos or videos of recorded people whose consent you do not have or that have not been informed, must be deleted immediately.

- Property protection: If using the camera for property surveillance or to investigate administrative offenses or crimes, ensure that only a perpetrator and not, for example, uninvolved persons are recorded.

- Handover to investigating authorities: Only if a misdemeanor offence has been committed, you may only hand over the recordings to the investigating and only to them. The investigating authorities will then decide on the further use of the recordings.

Note: Different laws may apply depending on the federal state. Seek professional legal advice in case of doubt.

Disclaimer

- In no event shall Technaxx Deutschland be liable for any direct, indirect punitive, incidental, special consequential damage, to property or life, improper storage, whatsoever arising out of or connected with the use or misuse of their products.
- This device is NOT intended to be used for illegal surveillance purposes and shall not be used in any form as evidence for claim purpose.
- Error messages may appear depending on the environment it is used in.
- Technaxx Deutschland is not liable/responsible for non- recording of events, missing files, etc.

Features

- FullHD video resolution 1920 x 2160 with max. 15fps
- Dual cameras for better overview of the scene
- Motion detection up to ~5-8m with automatically recording
- Wide viewing angle 88° horizontal & 40° vertical
- Rotation (270° horizontal & 90° vertical)
- 12x IR LED red glow (850nm) up to ~15m for B/W night vision
- 12x white LED (1.85W, 158lm, 4500K°) ~15m for colored vision at night
- Supports WiFi 2.4+5.8GHz IEEE802.11 b/g/n/ac/ax
- WiFi transmission distance up to max. 15m (open field)
- Brilliant 1/3" CMOS color sensor (2MP+2MP)
- Suitable for outdoor use, waterproof and dustproof IP65
- Free "Security Premium" APP for worldwide access [iOS & Android]
- Download of recordings via APP on to your Smartphone
- Alarm function (push message) on your Smartphone
- Built-in microphone & speaker for 2-way communication
- Supports MicroSD(HC/XC) cards up to 128GB* (Class 10) for local recording (*not included)
- H.264/H.265 video compression (for space-saving recordings of high quality)

Product overview

Camera

General information

Power connection

1. Connect the power supply to the camera power port, using the included power adapter.
2. Put the power adapter (DC12V/1A) into a power outlet.

MicroSD card

To insert the MicroSD card you need to remove the protective silicon and open the compartment on the bottom of the camera.



After inserting the MicroSD card with the notches facing left, as seen in the picture, close the compartment again.

Note: Take care while inserting the MicroSD into the slot. Otherwise it could happen that you put the MicroSD into the device instead of into the MicroSD slot.

Supports MicroSD card for local storage (max. 128GB). To guarantee the normal use of MicroSD card, before insert the MicroSD card, make sure its file system is FAT32 for 4-32GB and exFAT for 64-128GB. Check if there is more than 256MB space available.

For 64-128GB MicroSD cards it might be necessary to format the MicroSD card after inserting and configuration via the App. To work properly, the App must show the following status under device memory: Normal.

IR LED

The device activates the infrared light automatically as soon as low illumination prevails. There for the light option in the app needs to be set to infrared. With the IR LEDs shining at night you get black/white images/recordings at night.

White LED

The device activates the white light automatically as soon as low illumination prevails. There for the light option in the app needs to be set to

color. With the white LEDs shining at night you get colored images/recordings at night.

Status LED

The status LED is the green LED found on the LAN connector. It has three conditions:

Flashing fast:	Device is in WiFi pairing mode.
Flashing slow:	Device has no WiFi connection.
Continuous:	Device is connected to the WiFi / LAN.

RESET Button

Press and hold the reset button for 5 seconds to reset the device. Find the reset button next to the MicroSD card slot.

Quick operation guide

In this mode TX-328 camera can only be configured by iOS or Android APP!

Preparation

1. The camera needs to be connected to a power source via the included power adapter. After connecting the power adapter with the camera and the power socket. The LED indicator on the LAN port starts flashing fast. If the LED does not flash fast reset the device.

2. Insert a MicroSD card* into the MicroSD card slot for saving recordings (*not included).

Note: A MicroSD card should be inserted into the camera before it can be operated. Before inserting or removing the MicroSD card, the camera must be in OFF Mode. Failing to do so may cause loss of or damage to the videos already recorded on the MicroSD card.


Get App and add camera

→ To download the App Security Premium from the Appstore or the Playstore search for “Security Premium” or scan the QR-code below.


[iOS 15.0 or above; Android 12.0 or above (11-2023)]

		
APP icon	iOS	Android

- Open the Security Premium App on your device.
- Register Account.
1. On the login interface, click on register, enter the phone number/email, tick the box for data protection and terms of use and confirm.
 2. Follow the security request. Drag the tennis ball on the screen over the red button on to the racket.
 3. Enter the verification code from phone number or email and enter an account password and repeat it in the second column.
 4. Click on Confirm to create an account and login.

Log in Email/phone number password Forget password?Register Confirm ☒ Remember Password	Register Email/phone number Confirm ☐ Registration agree User Agreement And Privacy Policy Already have account, log in	Safety certification Drag the tennis ball on the screen to touch the racket through the red dot 	Setup password Verification code has been sent to test2@technaxx.de, please check. Verification code Get verification code again(103S) password password The password is 6-20 characters long, using numbers, symbols or letters and distinguish Capitalization Confirm
1	2	3	4

- (5) Click “+” on top right corner to add.
- (6) The App will search for devices nearby. Click on Add
- (7) Choose your WiFi network and enter the password for it. Confirm it.
- Follow the steps in the App:
- Change the device name to your needs, e.g. garden. Press on Next.
 - Enable Motion Detection Alert and Push messages. Press on Save configuration.
- (8) Installation is complete. Press on Finished.
- Important:** Change the password after you have added the camera successfully to the Security Premium App. Currently the camera has no password entered! A prompt will be shown on the camera image.




Mounting Alignment

When placing your camera, keep these tips in mind:

- Avoid placing the camera in an area that gets a lot of light shining directly into the camera lens.
- You can move and zoom the field of view.
- Keep active locations in the camera's field of view. The camera provides a 88° viewing angle and can rotate horizontal 270° and vertical 90°. Position your camera so that the space you want to monitor is within the camera's field of view.
- To help with placing your camera, do a live stream from the camera. Aim the camera while watching the video feed on your Security Premium smartphone App to make near-real-time adjustments to the camera's position.

Wall / Ceiling mount



- Find a place where you want to mount the camera. Make sure you have a power socket nearby.
- Mark the two bottom holes for camera mounting.

Note: If you drill a hole in the wall, please make sure that power cables, electrical cords and/or pipelines are not damaged. When using the supplied mounting material, we do not take the liability for a professional installation. You are entirely responsible to ensure that the mounting material is suitable for the particular masonry, and that the installation is done properly. When working at higher altitudes, there is danger of falling! Therefore, use suitable safeguards.

- Drill the two bottom holes into the wall and insert the dowels. Use a hammer for a flush finish with the wall. Screw in the screws. Make sure they are not completely screwed in.
- Hang the camera onto the two screws with the bottom holes.
- Now mark the top holes.
- Remove the camera.
- Drill the two top holes into the wall and insert the dowels. Use a hammer for a flush finish with the wall.
- Again, hang the camera onto the two screws with the bottom holes.
- Screw in the top screws to mount the device safely.





App pictures are based on Security Premium for iOS and Android in version 3.8.8 / 3.9.8

Security Premium App Registration

Please take several seconds to register.

(1) Click “Register”, (2) enter the email address to bind the email address. (3) Drag the tennis ball on the screen over the red button on to the racket. The system will send an email to your email address. Login to your email account, (4). Enter the verification code from phone number or email and enter an account password and repeat it in the second column. To complete registration press on confirm (follow these steps, otherwise users cannot use forget password function).

Info: When you are registered you have following advantage: Data added or grouped by user (e.g. the device), is managed by server, which won't be lost even to delete all data on the Smartphone. As long as users re-install the App and log in the old account, all data will be restored for some auxiliary functions such as device status notification and alarm notification.

			
1	2	3	4
Register	Enter Email	Safety certification	Enter verification code and password

Forget Password

If you forget the password and need to get it back, click „Forget password”. Enter the Email address into the user interface and press Confirm. The


system sends a confirmation Email, which the user can check via his Email account.

How to add a device


Add Device

Login to the App if not already done and go to “Device” interface.

iOS and Android:






- (1) Enable Bluetooth on your phone and click “+” on top right corner
- (2) The App will search for devices nearby. Click on Add
- (3) Choose your WiFi network and enter the password for it. Confirm it.
- (4) Camera is going to be configured.



- (5) Change the device name to your needs, e.g. garden. Press on Next.
- (6) Enable Motion Detection Alert and Push messages. Press on Save configuration.
- (7) Installation is complete. Press on Finished.
- (8) Change the password after you have added the camera successfully to the Security Premium App. Currently the camera has no password entered!

How to navigate in the App Device

In the Device interface you can see all your added devices. After clicking on the three dots next to the status (online, connecting, offline) you can set the device to the top, device settings, show manually taken Screenshot/Recordings, Edit or Delete the camera. Under the camera image you can find Share, News (Push) and Playback.

		
Device Interface	Live view Interface	Playback Interface

Live view

By clicking on the play button on the device interface you enter into real-time viewing. If the Smartphone can't connect to the device, it will show offline. If password is wrong, it will show wrong password, enter again. Click on the three dots right next to it and click on Edit. Here you can try to enter the password again.

Gesture operation

- Two fingers touch the screen and move outward to enlarge the image.
- Two fingers touch the screen and move inward to narrow the image.
- Single finger double clicks the screen to enlarge or narrow the image.
- Single finger slides left/right to rotate the image.


Button function list for Live view and Playback

	Device Setup	Click top right corner to backup videos or setup camera
	Connection	Shows the transmission speed of the data
	Resolution	Users choose the Resolution according to their needs. Note: HD = higher data consumption!
	Flashlight	Turn on/off the white LEDs manually
	Audio	Turn on/off the audio of the live view or the playback
	Screenshot	Take a screenshot of the live view. It will be stored on your Smartphone. Go to Me and click on Screenshot/Recording to view the taken pictures.
	Recording	Click to record the currently seen as video. Click again to stop recording and save the video file to your Smartphone. Go to Me and click on Screenshot/Recording to view the taken recordings.
	Full screen	Enlarge the image
	Playback	Playback videos stored on the MicroSD card
	Return	Return to live view
	Events	Shows alarm messages
	Preset	Set/call a preset

 	2-way-call	Click the blue to start the two way communication. To stop, click on red.
	Alarm	Enable the alarm sound on the camera manually. It will last for max. 15s or until you stop it manually.
	More	Shortcuts for quick access: - Motion detection: Enable/Disable - Tour: Enable/Disable - PTZ calibration - Infrared night vision: Enable/Disable - Photo album: Open to see saved photos / recordings

Device Setup

Clicking on Setup or Setting under the live view. It opens the Device setup below.



This interface can differ a little bit depending on the use of iOS or Android. All options are explained below.

Device Information

Device name	Chosen while configuration
Model	Device model
Signal	Signal strength of the WiFi network (Strong, middle, weak)
ID	The ID number of the device. This item cannot be filled in. Device ID will be automatically configured according to device type.
Firmware	Current installed firmware version Click and check if there is new software version. If there is, click and update directly to achieve OTA upgrade of the device. If the version is already the newest, there will be a prompt.

Motion Detection Alert

Motion Detection Alert	Enable/disable motion detection alarm. When the alarm function (motion detection) of the camera is triggered, the device will push the alarm message to our server and then the server will push the message to your Smartphone which bind push service and receive alarm push.
------------------------	---

Motion detection sensitivity	Select the sensitivity of the motion detection. Depending on the circumstances, a different attitude may be the best. Lowest about 1-2m; At the highest up to 10m
Humanoid detection	Motion detection will be more precise and you get alert when human is moving in front of the camera.
Picture frames in human form	Mark people in video through a frame
Motion Tracking	Enable/disable, when a human is detected, it will automatically follow the movement.
Motion detection period	Select or set the period time to: All day, Daytime, Night or Customize it
Motion detection area setting	Set/change the detection area or warning line. Improve the motion detection by deleting marked areas that often trigger motion detection.
Siren setting	Enable/disable to hear a siren sound from the camera with every detected motion. After you enabled the function you can choose to use the default sound or customize the alarm by recording your own sound.
White light alarm	Light warning will be triggered when human movement is detected.
Push message settings	
App push alert message	Enable / Disable
Notify me only when human appears	Enable / Disable
Message push period	Set the push period to: Push all day, Push during the day, Push at night or Customize it
Message interval	Set how often you want to receive a push: Every 2, 10 or 30 minutes.
Recording settings	
Record mode	Choose between Event recording or Uninterrupted recording
Video clarity	Set SD or HD
Record sound	Enable/Disable, when disabled there is no sound when viewing live and playback recordings
Timed video recording	Set a schedule when the camera should record.
Screen and sound settings	

Night vision mode	Set different modes: Smart night vision, Full color night vision, Infrared night vision, Infrared always on or Night vision off
Invert the image	Turn on when installing the camera upside down (NOT RECOMMENDED!)
Device call volume	Set the volume of the camera speaker
Anti-flicker setting	Adjust this setting if you have flickering problems
PTZ control	
PTZ speed	Choose between Low, Medium, High
Cruise mode	Choose Panoramic or Preset position cruise mode
PTZ calibration	Needs 30s to calibrate the PTZ function to work normal again after failure.
PTZ control direction flip	- Flip up and down: Enable/disable to change alignment - Flip left and right: Enable/disable to change alignment
Storage settings	
Local storage space	Show the status of MicroSD card (normal or abnormal). If the status is abnormal Format the MicroSD card. This takes about 3-5minutes. Shows used storage capacity of MicroSD card.
Download local video files	Shows you all recordings sorted by day and time saved to the MicroSD card.
Format the memory card	Click it to format the MicroSD card. The procedure is about 3-5 minutes and is not blocked by other operation. Note: 64 -128GB can be necessary to format via the App! It could be necessary to format until the App shows MicroSD status: Normal.
Advanced settings	
Device voice prompt	Change the language according to user's needs. Voice Prompt is mainly used for status information for the user
Signal strength	Shows the current strength of the WiFi connection
Connect new WiFi	Connect the camera to a new WiFi router
Time synchronization	Time syncing between Smartphone and camera.
Time zone setting	Time zone is set automatically. If not, adjust it here.
Daylight saving time	Enable/disable summertime. Choose country.

Setup password	Admin is a fixed username, cannot be changed. Click on password to change the old password to a new one.
Restart the camera	Click to restart the camera.
Delete and reset the camera	Click to reset the camera and delete the camera from your account.
About	
About this device	Shows the Camera model, Device ID, Software version, Connected WiFi, WiFi signal strength, IP address and MAC address.
Share device	Share device with another account here. Choose the permissions the person you share the device with is able to use.
Help and live chat	FAQ for questions

Playback

Click the button of remote  playback in the live view.


Precondition of camera remote playback:

→ Make sure the camera time is already time synchronized with the App
→ Insert the suitable MicroSD card into the camera. → enable motion detection recording.


Remote playback function of the device then only can be used.

→→ Choose the time by swiping the timeline left and right. →→ The red cursor marks the start time of playback. →→ Two fingers touch the timeline & move outward to narrow the time scale. →→ Two fingers touch the timeline and move inward to enlarge the time scale. →→ Press play in the middle of the shown image to start the playback

In the timeline you can find the color Green, Orange and a light Orange overlay. Green marks the recordings of human detection. Orange marks recordings of movement. The light Orange overlay marks the recordings of time (continuous or set schedule).



Playback Interface





Me

Me (personal area)

On this interface users can setup their account and App settings. See the picture above.

	See your account email address. Add cellphone number to bind and be able to login with. Change the password of your account. Check your login log. Like shown in the picture below.
 Settings (order differs on iOS and Android)	→ Enable/disable hard decoding (Android only) → Select the preview mode between real time or fluency. → Enable/disable Push notification banner → Click to upload a crash file after the app has crashed → Click to clear cache → Enable/disable the auto. screen brightness → Delete account permanently → Log out from the current account
 Screenshot / Video	Check screenshot / recording files See downloaded files here as well
 Share management	Devices that you share with other users are listed here.
 Help and Live Chat	Click here if you need some help with the installing of your camera.
 System authority settings	Check the permissions you gave the App and be able to change them.
 Company profile / About	See information about Technaxx like e.g. address
 Privacy policy	Check the privacy policy here.
 Configure APN	Change or configure the APN saved in the camera.

 Version	Check APP version and shows current APP version
---	---

	
Setup interface	Personal info (account) interface

The following chapter is based on Security Premium for Windows in version 2.0.7.11

PC Software Windows (& MAC)

Attention: It is not possible to configure the camera with the PC Software!

Info: The MAC version differs from the Windows version.

Installation

→ Start the Security Premium.exe which you find under www.technaxx.de/support --> TX-328

→ Double click on the Security Premium.exe to start the installation.

→ Choose the language and click on OK.

→ Agree to license agreement and click on I Agree.

→ Choose the path the software is installed to or keep the suggestion and click on install.

→ Wait until the installation is completed and click on Finish. The Software will start automatically.

Important: Maybe windows firewall pop up will show up. Select private or public network depending on your home network. If you are not sure choose both. Click on Allow access before going on with the Setup guide.


Login and add device

→ The PC Software starts automatically. A login window will show up. Just click on Login to use Local login.


→→ If you want to login with your registered App account (Cloud login) enter the email address (phone number) and the password, that you created for registration via the App.

Note: The advantage of cloud login is that all your added devices in your account are shown directly on the PC Software.

→→ If you choose the Local login, go to device management press on Add device and change to Cloud ID. Enter Cloud ID (Device ID on the device), User name (admin), password (specified camera password via App) and Device name (freely selectable). If you already added the device you will see it in the list on the right. Mark the added device by clicking on it and choose Edit.




Login page



Device management page


Open live view

To open the live view choose the Live view menu. Select the camera you want to view from the list on the right and click play button on the device. The live view opens in the black window with the red frame.



Playback recordings

Click on playback and to open it. The software will ask to close all currently opened live views (when there are open ones). Accept to close so you can change to the playback interface. Click on the + in front of the camera on the right and select the channel. Now press on retrieval. After searching is successful it will show colored bars in the timeline. Those are the recorded files saved on the MicroSD card inserted to the camera.



Troubleshooting

Problem	Solution
The camera takes photos / videos without any target objects in them (false triggers)	<u>-The PIR/motion sensitivity is set too high:</u> First check the camera's PIR sensitivity level in the App. <u>-Hot air:</u> The camera is triggered by detecting the movement of heat sources, so avoid mounting the camera near any equipment that emits hot air. <u>-Image change:</u> The camera is triggered by detecting the movement of humanoid or image changes, so e.g. shadows or moving leaves, trees can cause a motion detection. <u>-Reflecting light:</u> Light can trigger the camera, so avoid targeting the camera at anything that can reflect light (e.g. mirrors or moving bodies of water). <u>-Rising/setting sun:</u> So as to avoid targeting the sun as it rises or sets, mount the camera to face north or south. <u>Unstable mounting:</u> If the camera's mounting is not stable, then it may move and mistake this for the movement of objects in its field of view. When mounting the camera check that it is completely stable and avoid mounting it on anything that can move or shake. <u>Target objects moving too quickly:</u> In the case of fast-moving objects, e.g. animals, if the camera is positioned too close, or perpendicular to the target trail, there is a possibility that the trigger will not go off in time. a) Mount the camera further back from the trail b) Mount it at a 45° angle to the trail. <u>Tree leaves/branches:</u> Grass swaying in the wind, falling leaves or falling/moving tree branches/twigs can reflect the sun's heat and potentially cause false triggers. a) Mount the camera away from such objects, preferably slightly higher up (around 3-3.5m from the ground) to avoid swaying grass b) Clear the target area as much as possible of twigs, leaves and branches.

The camera is not capturing any videos	<u>-Camera is not turned ON:</u> First ensure that the camera is turned on checking the indicator LED at the RJ45 (LAN) connector. <u>-MicroSD card is full:</u> a) Upload the files saved on the MicroSD card to your computer, delete them from the card and re-use the same card, or: b) Put a new MicroSD card into the camera, or: <u>-MicroSD card is corrupted:</u> Due to physical damage, improper insertion/removal or viruses, MicroSD cards can become corrupted. If this happens, you will need to format/reformat the MicroSD card.
Night vision range is limited	<u>-“Night Mode” is not set correctly:</u> First ensure that “Night Mode” is set to “Intelligent”. <u>-Nearby light source:</u> If there is a significantly bright light source near the camera it may interfere with the functioning of the camera’s night vision. Avoid placing your camera near a bright light source. <u>-Target area is too open:</u> The camera’s night vision works via infrared light that is emitted and reflected back off the objects in the target area, then captured by the camera’s image sensor. Therefore, if the target area is too open, i.e. with very few objects to reflect the IR light, then the night vision image will appear very dark. For night vision purposes, target the camera at an area that contains objects, e.g. trees, bushes, walls, etc.
No preview	The server may be congested, try restarting the app.
No push notification	Make sure the app has notification permissions. Confirm that the alarm message push switch is turned on in the App Personal Center settings. Confirm that the alarm message push switch is turned on in the camera settings.
No recording	Insert MicroSD card before booting. Make sure the camera motion detection (monitoring) switch is turned on. (App) Make sure the camera recording switch is turned on (App).

	Check whether the MicroSD card status is normal in the App. If it is abnormal, try to format the MicroSD card.
Unsuccessful network configuration	Make sure your phone, camera, and router are close enough. Check that the router name and password are correct.
Device is offline	Check your router's Internet connection. Check the connection between the camera and the router. If you change the router or change the WiFi password, you need to reset the camera and reconfigure the network.

FAQs

Q1: When adding device by LAN or serial number, it warns “device is not online” or “device is not registered”

A1: Make sure the internet connection which the device is using could access to internet normally. Check if the router has opened the DHCP function. If you have changed the network parameters of the device manually, we suggest to press RESET button for 5 seconds and make the device to restore to factory settings.

Q2: What should I do if I forget my App password?

A2: If you have forgotten the login password of the App account, please reset the password through the "Forgot Password" option in the login interface as instructed.

The device's access password is set after the device is added or modified by the App, and the App remembers it. Subsequent access does not need to be re-entered.

Q3: Why it reports “memory card fault” when insert the MicroSD card?

A3.1: The device only supports the FAT32 file system and storage should not be above 128GB. Confirm the file system type and whether the MicroSD card capacity is beyond the normal use scope.

A3.2: The MicroSD card appears some damage, the device couldn't read and write as usual, which needs to reformat by computer before using. Format 64-128GB on PC to exFAT if possible.

Q4: Why the playback is intermittent?

A4: Due to the limited use life of the MicroSD cards, the continuous video will largely reduce the MicroSD card life, when the device detects the

moving images, the intermittent condition could save storage space and prolong the MicroSD card life.

Q5: The device is online and also there is motion happening in surveillance area, but why not receiving alarm information on mobile phone?

A5.1: Make sure that the device IP from APP is running on the mobile and motion detection function has been enabled.

A5.2: Check if you opened the “message notification” function on your Smartphone system.

Technical Specifications

Image sensor	2MP+2MP 1/3" CMOS dual
Lens	f=4mm, fixed focus
Viewing angle	horizontal: 88°/ vertical: 40°
Day & Night	Auto. IR-cut filter
Minimum illumination	Color mode: 0.01 Lux; Night mode: 0 Lux with 12x IR LED or 12x white LED
IR distance	~15m; IR 850nm, White 1.85W, 158lm, 4500K
Rotation angle	Horizontal: 0-270°; Vertical: 0-90°
Video resolution	HD (1920x2160), Smooth (800x896)
Video frame rate	15fps (PAL 50Hz, NTSC 60Hz)
Video file format	.MP4
Video compression	H.264/H.265
Audio source	Built-in microphone
Audio compression standard	G726/G711A/AAC-8K16bits
Audio compression code stream	Streaming self-adaptive
Speaker	Built in, 8Ω 1W
Network	2.4 & 5.8GHz 802.11b/g/n/ac/ax
WiFi security	WPA/WPA2, WPA-PSK/WPA2-PSK
WiFi distance	Max. 15m (open field)
Radiated output power max.	100mW
Motion detection	Distance: ~5-8m (open space)
Storage	Supports MicroSD(HC/XC) cards up to 128GB (FAT32/exFAT) (class10)
File size	Night; B/W or Day; colour: 13MB/min (32GB = 1.5 days continuous ¹ recording)
Power consumption	Day ≤ 3W / Night ≤ 8W
Power adapter	DC 12V / 1A, hollow connector 5.5 x 2.1mm
Cable length	3m
Working condition	-10 - 45°C; RH Less than 95% (No condensation)

Protection class	IP65
App "Security Premium"	iOS 13.0 or above; Android 10.0 or above / EN, DE, FR, ES, IT, NL, SE, DK, NO, FI, CZ, PO (11-2023)
Material	ABS Plastic
Weight / Dimension	320g / (L without antenna) 20.5 x (W) 14.5x (H) 10cm
Package contents	Dual Camera Outdoor TX-328, 1x Power Adapter (3m), 4x Screws & Dowels, User Manual (short)

¹continuous = the needed storage was calculated by continuous recording. Because it is hard to estimate the individual triggers of motion and the resulting storage need.

Support

Service phone No. for technical support: **01805 012643** (14 cent/minute from German fixed-line and 42 cent/minute from mobile networks). Free Email: **support@technaxx.de**

The support hotline is available Mon-Fri from 9am to 1pm & 2pm to 5pm
In the event of anomalies and accidents, please contact: **gpsr@technaxx.de**

Care and maintenance

Clean the device only with a dry or slightly damp, lint-free cloth.

Do not use abrasive cleaners to clean the device.

This device is a high-precision optical instrument, so in order to avoid damage, please avoid the following practice:

- Use the device in ultra-high or ultra-low temperature.
- Keep it or use it in moist environment for long.
- Use it in rainfalls or in water.
- Deliver or use it in strongly shocking environment.

Declaration of Conformity



Technaxx Deutschland GmbH & Co. KG hereby declares that the radio equipment type TX-328 Prod. ID.:5280 is in compliance with Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following internet address: www.technaxx.de/reseller

Disposal



Disposal of the packaging. Sort packaging materials by type upon disposal.

Dispose of cardboard and paperboard in the waste paper. Foils should be submitted for recyclables collection.



Disposing of old equipment (Applies in the European Union and other European countries with separate collection (collection of recyclable materials) Old equipment must not be disposed of with household waste! Every consumer is required by law to dispose of old devices that can no longer be used separately from household waste, e.g. at a collection point in his or her municipality or district. This ensures that the old devices are properly recycled and that negative effects on the environment are avoided. For this reason, electrical devices are marked with the symbol shown here.

Made in China

Distributed by:
Technaxx Deutschland GmbH & Co. KG
Konrad-Zuse-Ring 16-18,
61137 Schöneck, Germany

Dual Camera Outdoor TX-328

This product includes software developed by third parties, including software which is released under the GNU General Public License Version 2 (GPL v2). This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version. You may obtain a complete machine-readable copy of the source code for the above mentioned software under the terms of GPL v2 without charge except for the cost of media, shipping, and handling, upon written request to Technaxx Deutschland GmbH & Co. KG, Konrad-Zuse-Ring 16-18, 61137 Schöneck, Germany.

This program is distributed in the hope that it will be useful, but **WITHOUT ANY WARRANTY**; without even the implied warranty of **MERCHANTABILITY** or **FITNESS FOR A PARTICULAR PURPOSE**. See the GNU General Public License for more details. You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA. (Notice from Technaxx: A copy of the GPL is included below).

GNU GENERAL PUBLIC LICENSE: Version 2, June 1991 / Copyright (C) 1989, 1991 Free Software Foundation, Inc. / 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA. Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights. We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone

else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all. The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program. You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself

is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a)** Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b)** Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c)** Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or

by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

HOW TO APPLY THESE TERMS TO YOUR NEW PROGRAMS

(1) If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

(2) To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and an idea of what it does.>

Copyright (C) <yyyy> <name of author>

(3) This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

(4) This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

(5) You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation Inc; 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA.

(6) Also add information on how to contact you by electronic and paper mail.

(7) If the program is interactive, make it output a short notice like this when it starts in an interactive mode: Gnomovision version 69, Copyright (C) year name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'.

(8) This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

(9) The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicks or menu items--whatever suits your program.

(10) You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample;