

# Technaxx® \* User Manual

## GPS Smartwatch TX-SW3HR

The manufacturer Technaxx Deutschland GmbH & Co.KG hereby declares that this device, to which this user manual belongs, complies with the essential requirements of the standards referred to the Directive **RED 2014/53/EU**. The Declaration of Conformity you find here: [www.technaxx.de/](http://www.technaxx.de/) (in bar at the bottom "Konformitätserklärung"). Before using the device the first time, read the user manual carefully.

Service phone No. for technical support: 01805 012643 (14 cent/minute from German fixed-line and 42 cent/minute from mobile networks).

Free Email: [support@technaxx.de](mailto:support@technaxx.de)

**This device has a rechargeable battery. It must be fully charged before first use. NOTE: Charge the battery of the device every 2–3 month if it is not used!**

Keep this user manual for future reference or product sharing carefully. Do the same with the original accessories for this product. In case of warranty, please contact the dealer or the store where you bought this product.

**Warranty 2 years**

***Enjoy your product \* Share your experience and opinion on one of the well-known internet portals.***

### Features

- GPS Smartwatch to monitor your sport activities, heart rate, your fitness and your sleep activities
- Displays heart rate, steps, distances, burned calories, sleep time, clock & date
- Notification reminder: calls, SMS, Email, WhatsApp, social media, achieved goals, activity reminder, drink reminder
- Free FunDo Pro APP in Google Play Store and Apple AppStore
- Anti-lost function: find your mobile phone or the Smartwatch
- Waterproof according to protection class IP67
- 20 days usage time and 50 days standby time
- Wake up screen by turning your wrist



## Technical specifications

Display	1.3" Round Color Screen (240*240 Pixel)	
Processor	Nordic 52832	
Heart rate sensor	HRS3300	
Protection class	IP67	
Bluetooth / Distance	Version 4.0 BLE / ~10m	
BT transmitting frequency	2.4GHz	
BT max. radiated output power	2.5mW	
Power supply	Built-in rechargeable 460mAh Lithium-polymer battery 3,8V	
Operating time	~20 days usage / ~50 days standby	
Charging time	~3 hours (use the magnetic charging cable with an USB charging adapter)	
APP	FunDo Pro	
Supported APP Languages	GB, DE, FR, ES, PT, IT, PL, NL, RU, CZ, TR (November 2018)	
Weight / Dimensions	45g / (L) 40.8 x (W) 40.8 x (H)15.5mm	
Storage temperature / Operation temperature	-20°C up to 45°C	
Package Contents	Technaxx® GPS Smartwatch TX-SW3HR, charging cable, user manual	
Compatibility	Android 4.3 or above & iOS 8.0 or above	




**Hints for Environment Protection:** Packages materials are raw materials and can be recycled. Do not disposal old devices or batteries into the domestic waste. **Cleaning:** Protect the device from contamination and pollution. Avoid using rough, coarse-grained materials or solvents/aggressive cleaner. Wipe the cleaned device accurately. **Distributor:** Technaxx Deutschland GmbH & Co.KG, Kruppstr. 105, 60388 Frankfurt a.M., Germany

## Charging

	<p>Plug the magnetic USB charger in a USB-port with power source</p>
	<p>Now connect the magnetic charger to the watch to charge it</p>

## Product overview

			
1	Display	3	Heart rate sensor
2	Crown-button	4	Charging pins

**NOTE: The device should be charged at least 1 hour before use.**

## Start up

Connect the Smartwatch with the magnet charger or press down the crown button for 2 seconds.

## Install FunDo Pro APP on your Smartphone

Search for “**FunDo Pro**” APP in the Google Play Store/Apple APP-Store or scan the following QR code for the installation.



Google Play Store



Apple App Store

## Connect the Smartwatch with the FunDo Pro APP



Wait until the device is fully charged. Activate the Bluetooth of your Smartphone. Then open the APP. Confirm all requests to get the most out of the APP. Press “Add device” under “More” and search for “**TX-SW3HR**”. Choose “**TX- SW3HR**” from the list and you are ready. Now the Smartwatch is connected with your Smartphone and the APP.

**INFO:** If the last mobile device connected to your Smartwatch is turned on and the Bluetooth function is activated on both devices, then the Smartwatch will automatically connect with the mobile device.

## Start using

When the Smartwatch is connected to the APP successfully, it will synchronize the time and the date. It counts steps, distance and calories automatically. Press the Crown-Button to activate the lcd screen. Swipe left to see all functions. Swipe right to go back. Swipe up or down on the start to see the main functions. Swipe right on start screen to see notifications.

## Main screen

			
Battery/Date/Time	Steps	Heart rate	Bluetooth


## Pedometer

	Swipe left until you see this icon. Tap this icon to enter this option. The Pedometer counts footsteps, calculates the distance and calorie consumption. Swipe down for historical data from the whole week.
---	--

## Select a sport

	Swipe left until you see this icon. Tap this icon to enter this option. Now you can choose between different sports. Swipe down until you have reached the desired sport. Now push the desired sport to start the workout. After the gps is found the tracking begin.
--	---

## QR-Code for APP

	Swipe left until you see this icon. Tap this icon to enter this option. Now you see a QR-Code. Scan it to go to the Appstore page for the App FunDo Pro
---	---

## Heart rate

	Swipe left until you see this icon. Tap this icon to enter this option. Your heart rate will now be measured.
---	---

## Sports historical data

	<p>Swipe left until you see this icon. Tap this icon to enter this option. Now you see your historical sport activities chronological.</p>
---	--

## Sleep monitor

	<p>Swipe left until you see this icon. Tap this icon to enter this option. If you would like to monitor your sleep quality based on your sleeping time, you should wear the Smartwatch on your wrist while you go to sleep. Swipe down for historical data.</p>
---	---

## Music player

	<p>Swipe left until you see this icon. Tap this icon to enter this option. Now you can start and stop the music by pressing the play/pause button, previous or next title.</p>
--	--


## Alarm

	<p>Swipe left until you see this icon. Tap this icon to enter this option. Here you see the Alarm you can set in the App.</p>
---	---

## Messages / Push-Notifications

	<p>Swipe right and you see your Push-Notifications like missed calls, SMS, WhatsApp, Twitter, Instagram, Facebook, Messenger, etc.</p>
---	--

## Countdown



Swipe left until you see this icon. Tap this icon to enter this option. Select a Time and press start to begin a countdown.

## Stopwatch




Swipe left until you see this icon. Tap this icon to enter this option. Press start to begin. Press reset for a lap time and stop and reset to zero the stopwatch

## Phone finder



Swipe left until you see this icon. Tap this icon to enter this option. Now the Smartwatch send a notification to your phone and it begin to ring. Note: If there is no Bluetooth connection, the option is not available

## Settings



Swipe left until you see this icon. Tap this icon to enter this option. Here you can change the brightness / lcd time and see the system informations. Reset is also available over this option.

## Power-Off

Hold down the crown button for 2 seconds. The smartwatch vibrates before turning off.

## Hints

- Bluetooth connection becomes disconnected when the device exceeds a certain distance.
- Reconnect with Bluetooth if Bluetooth does not work for more than 5 min.
- Before binding the bracelet to another account, you need to unbind it with the current account.
- If the bracelet cannot be illuminated, connect the bracelet to the charger.

## **Safety instructions**

● Rebuilding or modifying the product impairs product safety. ● All modifications and repairs of the device or accessories must be performed by the manufacturer or by persons expressly authorized by the manufacturer. ● Never open the product by yourself or perform repairs by yourself! ● Handle the product carefully. It can be damaged by knocks, blows or even by falling from low height. ● Keep the product away from damp, moisture and extreme heat. ● Never immerse the product in water or other fluids. ● Technical specifications are subject to change without notice. ● Never heat the battery above 60°C and do not drop or throw it into the fire, danger of explosion/fire hazard! ● Do not short-circuit the battery. ● Do not subject the battery to mechanical stress. Avoid dropping, striking, bending, twisting or cutting the battery. ● Discontinue the charging process immediately should the battery become overheated. A battery that becomes overheated or deformed during the charging process is defective and should no longer be used. ● Never drain the battery completely, as this shortens its lifetime. ● If the battery must be stored, it is recommended that it be stored at 30% of its loading volume. Store out of direct sunlight. Ideal storage temperature: 10–20°C. ● Keep the product away from little children.

## **Disposal**

### **Old electrical appliances from private households**

● If you no longer want to use the appliance, hand it in free of charge at a public collection point for old electrical appliances. ● Old electrical appliances must never be placed in the residual waste bins.

### **Further disposal instructions**

● Return the old electrical appliance in such a way that its subsequent reuse or recycling is not impaired. Batteries must be removed beforehand and the destruction of containers containing liquids must be avoided. ● Old electrical appliances can contain harmful substances. If the device is handled incorrectly or damaged, this can lead to damage to health or water and soil contamination when the device is later recycled.