

# Trendgeek® user manual

## Kids Learning Clock TG-132

Before using the appliance for the first time, please read the instructions for use and safety information carefully.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capacities, or by persons lacking in experience or knowledge, unless they are supervised or instructed on the use of this device by a person responsible for their safety. Children should be supervised to ensure they do not play with this device.

Keep this user manual for future reference or product sharing carefully. Do the same with the original accessories for this product. In case of warranty, please contact the dealer or the store where you bought this product.

### Features

- Helps children learn how to tell time
- Encourages understanding of daily routines
- Easy-to-read dial design
- Low-noise operation

### Declaration of Conformity

The EU Declaration of Conformity can be requested at the following address: [www.technaxx.de/](http://www.technaxx.de/) (in the lower bar "Declaration of Conformity").

### Disposal



Disposal of the packaging. Sort packaging materials by type upon disposal. Dispose of cardboard and paperboard in the waste paper. Foils should be submitted for recyclables collection.




Disposing of old equipment (Applies in the European Union and other European countries with separate collection (collection of recyclable materials) Old equipment must not be disposed of with household waste! Every consumer is required by law to dispose of old devices that can no longer be used separately from household waste, e.g. at a collection point in his or her municipality or district. This ensures that the old devices are properly recycled and that negative effects on the environment are avoided. For this reason, electrical devices are marked with the symbol shown here.

### Technical specifications

Time accuracy	± 2 seconds per day
Alarm accuracy	± 5 minutes
Battery	1x AA
Working temperature	5°C – 40°C
Weight / Dimension	221g / 11.3 x 11.7 x 5.5 cm
Package content	Kids Learning Clock TG-132, user manual

### Product Overview



1	Light	2	Alarm ON / OFF
3	Set Time	4	Set Alarm
5	Battery cover		

#### Installing the Battery

Open the battery cover (5) on the back of the clock. Insert one new AA battery according to the polarity markings.

#### Setting the Time

Turn the time-setting dial (3) on the back until the correct time is displayed. (Red = Minutes / Blue = Hours)

#### Setting the Alarm

Adjust the alarm-setting dial (4) to the desired wake-up time. Note: Due to the 12-hour time format and the hour-based trigger, the alarm will activate two times each day. Alarm accuracy ± 5 minutes.

#### Turning the Alarm ON/OFF

Slide the ON/OFF switch (2) to the "ON" position to activate the alarm. Slide to "OFF" to deactivate the alarm.

#### Light Function

- Press and hold the light button (1).
- The light turns on.
- Release the light button to turn it off.

### Safety instructions

•Observe the safety instructions during use. •Any modification or alteration of the product will affect the safety of the product. Caution risk of injury! •Do not use in humid or dusty environments. •Protect from strong impact. •Use high-quality AA batteries only. •Remove battery if not used for long periods. •Not a toy – supervise children. •All changes and repairs to the product or its accessories may only be carried out by the manufacturer or by persons expressly authorized by the manufacturer. •Never open the product without authorization. •Never carry out repairs yourself! •Handle the product with care. It can be damaged by shaking or falling from a small height. •Never immerse the product in water or other liquids. •Technical changes and errors reserved.

### WARNING

- This product is not a toy.
- Use under adult supervision.
- Keep out of reach of small children.
- Contains small parts.
- Batteries must be kept away from children.
- If a battery is swallowed, seek immediate medical attention.

### Support

Service phone No. for technical support: **01805 012643** (14 cent/minute from German fixed-line and 42 cent/minute from mobile networks). Free Email: [support@technaxx.de](mailto:support@technaxx.de)  
The support hotline is available Mon-Fri from 9 am to 1 pm & 2 pm to 5 pm.

### Cleaning and maintenance

•Clean the equipment regularly with a moist cloth. •Do not use cleaning agents or solvents. •If not used for long periods of time please remove the battery.

Made in China

Distributed by:  
Technaxx Deutschland GmbH & Co. KG  
Konrad-Zuse-Ring 16-18,  
61137 Schöneck, Germany