

Technaxx® user manual

Mini Battery Air Pump TX-261

Before using the appliance for the first time, please read the instructions for use and safety information carefully.

Keep this user manual for future reference or product sharing carefully. Do the same with the original accessories for this product. In case of warranty, please contact the dealer or the store where you bought this product.

Features

- Powerful air pump
- Large battery
- Can be used anywhere
- LED camping light
- With 5 nozzles, suitable for most small and large inflatable products, such as air mattresses, inflatable beds, sleeping pillows, swimming rings, inflatable furniture and other inflatable toys

Declaration of Conformity

The EU Declaration of Conformity can be requested at the following address: www.technaxx.de/ (in the lower bar "Declaration of Conformity").

Disposal


Disposal of the packaging. Sort packaging materials by type upon disposal. Dispose of cardboard and paperboard in the waste paper. Foils should be submitted for recyclables collection.

Disposing of old equipment (Applies in the European Union and other European countries with separate collection (collection of recyclable materials) Old equipment must not be disposed of with household waste! Every consumer is required by law to dispose of old devices that can no longer be used separately from household waste, e.g. at a collection point in his or her municipality or district. This ensures that the old devices are properly recycled and that negative effects on the environment are avoided. For this reason, electrical devices are marked with the symbol shown here.

Technical specification

Inflation speed / pressure	180 L/min / 3.5 kPa (max.)
Power	13.5 W
Battery capacity	1360 mAh / 3.7 V
Charging input	DC 5 V / 0.8 A (USB Type C port)
Charging time	Approx. 1.5 h
Running time	Up to 15 min inflation or 5 h LED light
LED	40 / 200 / 400 Lumen
Working temperature	-10 – 45°C
Weight / Dimension	79 g / 5.1 x 4.4 x 4.4 cm
Package content	Mini Battery Air Pump TX-261, 5 nozzle, charging cable, bag, user manual

Product Overview



1	Deflation (air inlet)	2	Inflation (air outlet)
3	LED light	4	Switch button
5	USB-C charging port	6	Indicator LED

Nozzels

Universal / Vacuum bags	Air mattresses / toys	Inflatable beds (20mm / 16mm)

Inflate

- Attache the best fitting nozzle to the air outlet (2) to inflate the product you want to pump up.
- Double press the switch button (4) to start inflation.
- Double press the switch button (4) to stop inflation.

Deflate

- Attache the best fitting nozzle to the air inlet (1) to deflate the product you want to pump off or vacuum.
- Double press the switch button (4) to start deflation.
- Double press the switch button (4) to stop deflation.

LED

- Press and hold the switch button (4) at least 3 seconds to turn on the LED light
- Press again to change to 200 or 400 Lumen light

Charging

- Insert one end of the randomly delivered USB cable into a power adapter (DC5V/2A or higher current adapter, not attached), and the other end into the TYPE-C charging interface of the machine to start charging.
- The red indicator light will light up during charging, the green indicator light will light up after fully charged.

CAUTION

- Do not use continuously for more than 10 minutes.
- Do not invade water or other liquids.
- Keep the air outlet and inlet clean.
- Do not reach into the air outlet or air inlet.
- Keep children away from the device.
- Keep away from flammable and explosive materials.
- Do not throw in fire – it will explode due to built-in battery.

Safety instructions

• Observe the safety instructions during use. • Any modification or alteration of the product will affect the safety of the product. Caution risk of injury! • All changes and repairs to the product or its accessories may only be carried out by the manufacturer or by persons expressly authorized by the manufacturer. • Never open the product without authorization. • Never carry out repairs yourself! • Handle the product with care. It can be damaged by shaking or falling from a small height. • Never immerse the product in water or other liquids. • Technical changes and errors reserved.

Support

Service phone No. for technical support: **01805 012643**
(14 cent/minute from German fixed-line and 42 cent/minute from mobile networks). Free Email: support@technaxx.de
The support hotline is available Mon-Fri from 9 am to 1 pm & 2 pm to 5 pm.

Cleaning and maintenance

• Clean the equipment regularly with a moist cloth. Do not use cleaning agents or solvents. • Ensure that no water can seep into the plugs. The ingress of water into an electric device increases the risk of an electric shock or damage of the device.

Made in China

Distributed by:
Technaxx Deutschland GmbH & Co. KG
Konrad-Zuse-Ring 16-18,
61137 Schöneck, Germany