# Lifenaxx® \* User Manual Espresso To Go LX-060

Before using the appliance for the first time, please read the instructions for use and safety information carefully.



This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capacities, or by persons lacking in experience or knowledge, unless they are supervised or instructed on the use of this device by a person responsible for their safety. Children should be supervised to ensure they do not play with this device.

Keep this user manual for future reference or product sharing carefully. Do the same with the original accessories for this product. In case of warranty, please contact the dealer or the store where you bought this product.

# Enjoy your product. \* Share your experience and opinion on one of the well-known internet portals.

Specifications are subject to change without notice - please be sure to use the latest manual available on the manufacturer's website.

#### **Table of Contents**

Hints 2	Installation steps 6
Safety instructions2	Big Capsule7
Safety rules for rechargeable	Small Capsule 7
batteries3	Coffee powder7
Warnings 3	Coffee/Espresso Brewing 7
Disclaimer3	FAQs 9
Features 4	Technical specifications 9
Product overview5	Support 10
Charging 5	Declaration of Conformity 10
Instruction for use6	Disposal10

#### **Hints**

Only use the product for purposes due to its intended function ● Do not damage the product. Following cases may damage the product: Incorrect voltage, accidents (including liquid or moisture), misuse or abuse of the product, faulty or improper installation, mains supply problems including power spikes or lightning damage, infestation by insects, tampering or modification of the product by persons other than authorized service personnel, exposure to abnormally corrosive materials, insertion of foreign objects into the unit, used with accessories not preapproved. ● Refer to and heed all warnings and precautions in the user manual.

#### Safety instructions

- It is intended for use by private individuals.
- Never touch the product with wet or damp hands.
- The product can only be operated with the voltage described on the sticker.
- Do not place the product on an unstable surface. The unit could be damaged or persons could be injured. Any attachments should be made only in accordance with the manufacturer's instructions or obtained from the manufacturer.
- The cable is sheathed and insulates the current. Do not place any objects on the cable, as this could cause the protective function to be lost. Avoid placing excessive stress on the cable, especially at sockets and plugs.
- Do not insert any objects into the openings of the unit, as current flows in some places and contact may cause fire or electric shock.
- Do not use liquid cleaners or cleaning sprays. The product may only be cleaned with a damp cloth.
- Do not connect any additional devices that are not recommended by the manufacturer.

• Do not use the product in direct sunlight or places where the temperature may exceed 50°C for a long time.

# Safety rules for rechargeable batteries

The product uses rechargeable batteries and can go wherever you need them. But ALL batteries can EXPLODE, CATCH FIRE, and CAUSE BURNS if disassembled, punctured, cut, crushed, short-circuited, incinerated, or exposed to water, fire, or high temperatures, so you must handle them with care.

To use the rechargeable batteries safely, follow these guidelines:

- ALWAYS follow local waste and recycling laws when throwing used batteries away.
- ALWAYS use the product to charge the rechargeable batteries.
- NEVER place the rechargeable batteries in a pocket, purse, or other receptacle, especially those containing metal objects.
- NEVER store the rechargeable batteries with hazardous or combustible materials.
- NEVER let the rechargeable battery or battery compartment get wet before, during, or after installation. (Remember, your product itself is weatherproof, but its interior battery compartment and batteries aren't.)
- NEVER disassemble, cut, crush, puncture, short-circuit, dispose of batteries in fire or water, or expose the rechargeable battery to temperatures above 50°C.

#### Warnings

- Do not disassemble the product, it may result in short-circuit or damage.
- Battery life-span will decrease with usage. Charge the battery at least once every month to preserve battery in the event the product is not used for long time. Battery warning: Improper use of the battery may cause fire or chemical burns. The battery may explode in case of damage. Do not modify, repair or remove without professional guidance. Do not use corrosive or volatile liquid for cleaning. Do not drop or shake the device, it may break internal circuit boards or mechanics. Keep the device away from little children.


#### **Disclaimer**

● In no event shall Technaxx Deutschland be liable for any direct, indirect punitive, incidental, special consequential danger, to property or life, improper storage, whatsoever arising out of or connected with the use or misuse of their products.

#### **Features**

- Compact size and lightweight design: Ideal for on the go, traveling, camping or for use in the office. Fits in backpacks or handbags and saves space.
- Battery-powered: The rechargeable battery enables operation without a plug socket, so the machine can be used anywhere, e.g. in the car, when camping or during outdoor activities. Long battery life for several cups.
- Versatile compatibility: The machine can be used with both capsules and ground coffee, giving you the choice between convenient capsules and freshly ground powder.
- Fast heat-up time: Thanks to fast heat-up technology, coffee/espresso is prepared in just a few minutes, ideal for a quick coffee break on the go.
- User-friendly operation: Simple one-button controls that allow the machine to be operated with minimal effort, without complicated settings.
- Rechargeable battery: The batteries are rechargeable via USB-C, allowing for easy handling and flexibility when charging.
- High-quality materials: Robust, lightweight housing made of ABS + 304 stainless steel + PA/GF for a long service life and easy cleaning.
- Water tank: A sufficient amount for a small cup of coffee / espresso.

#### **Product overview**



## Charging

- 1. Charge the device in time when red LED running. Red LED is running when it's in charging. Green LED will be on after fully charged.
- 2. As long as the USB cable is connected, the device cannot perform a heating or brewing process. Disconnect the cable when the device is fully charged. Only then can the heating or brewing process be started.

# Instruction for use *Caution:*

- 1. Don't touch green pad on the cap when it's heating. Keep children away from device when it's heating.
- 2. Don't start heating precess if there is no water inside, even though there is anti-dry heat protection for 145°C. At the status of anti-dry heat protection, LED flashes 5s red and peeps 5s.
- 3. Clean the device and keep it dry after use.

LED Color	Working Status
Red: LED flashes 5s	Anti-dry heat protection
Orange: LED pulsating	Heating up
Green: LED rotating	Brew
Red: LED rotating	Brew (battery below 25%)


**Installation steps** 



#### Compatible Capsules



# **Big Capsule**



# **Coffee/Espresso Brewing**

You can choose cold water or hot water for brewing.

# For cold water, operate as below steps:

1. Take cap off, pour cold water into water container (max. 60ml) then close the cap.

- 2. Press power button once to check battery level (green LED on), then long press power button to brew cold coffee/espresso (green LED rotating), Red LED is rotating when battery level below 25%.
- 3. If heat the cold water, press button twice to heat the water to 86°C within 5mins (orange LED pulsating), it peeps 4 times and automatically brewing hot coffee/espresso for 60s (green LED rotating).

#### For hot water, operate as below steps:

- 1. Take cap off, pour hot water into water container then close the cap.
- 2. Press power button once to check battery level (green LED on), then long press power button to brew hot coffee/espresso this takes 60s (green LED rotating).

# **FAQs**

Malfunction	Analysis	Troubleshooting
Red light is on for	Ran out of	Charge it for 3 to 5 hours to make
8 seconds	battery	sure that it gets a full recharge.
Red light flashes	Heat time over	Restart. Double click power button
slowly with buzzer	15 mins, device	to heat water
sounds for 5	stop working	
seconds		
Red light flashes	Over-heating	Take cap off to cool it down for 5
quickly with	protection	mins. Then re-heat by double
buzzer sounds for		clicking power button.
5 seconds		
Extraction of water	Big capsule or	Twist the big capsule holder tightly
only	small capsule is	to the end until it can't be screwed.
	not pricked well	
Extracted ground	<u> </u>	Make sure no overflew coffee
	is overflowed on	powder around the powder holder
residue	the holder edge	and use a spoon to press coffee
		powder tightly for a better brewing.

**Technical specifications** 

recinical specificat			
Water capacity	60 ml		
Cup capacity	120 ml		
Power supply	USB-C 5V / 2A		
Battery capacity	3x 18650 / 2500 mAh		
Power	72 W		
Working voltage	12 V		
Heat time	5 min		
Max. heat time	Up to 15 min		
Brewing time	60 s		
Ant-Dry burning temp.	145 °C		
Water heating temp.	86 °C		
Charging time	3-5 hours		
Usage 1x full charged	5x heat & brew + 5x brew		
Material	ABS+304+PA/GF		
Weight & Dimensions	668g / (L) 8.35x (W) 8.35x (H) 24.6cm		
	1x Espresso To Go LX-060, 1x big capsule		
Package contents	holder, 1x small capsule holder, 1x coffee		
	powder holder, 1x cup, 1x user manual		

## **Support**

Service phone No. for technical support: **01805 012643** (14 cent/minute from German fixed-line and 42 cent/minute from mobile networks). Free Email: **support@technaxx.de** 

The support hotline is available Mon-Fri from 9am to 1pm & 2pm to 5pm In the event of anomalies and accidents, please contact: **gpsr@technaxx.de** 

#### **Declaration of Conformity**



Technaxx Deutschland GmbH & Co. KG hereby declares that the equipment type LX-060 Prod. ID.:5315 is in compliance with Directive 2014/30/EU. The full text of the EU Declaration of Conformity is available at the following internet address: www.technaxx.de/reseller

### **Disposal**



Disposal of the packaging. Sort packaging materials by type upon disposal.

Dispose of cardboard and paperboard in the waste paper. Foils should be submitted for recyclables collection.



Disposing of old equipment (Applies in the European Union and other European countries with separate collection (collection of recyclable materials) Old equipment must not be disposed of with household waste! Every consumer is required by law to dispose of old devices that can no longer be used separately from household waste, e.g. at a collection point in his or her municipality or district. This ensures that the old devices are properly recycled and that negative effects on the environment are avoided. For this reason, electrical devices are marked with the symbol shown here.



Batteries and rechargeable batteries must not be disposed of in household waste! As a consumer, you are required by law to dispose of all batteries and rechargeable batteries, whether they contain harmful substances\* or not, at a collection point in your community/city or with a retailer, to ensure that the batteries can be disposed of in an environmentally friendly manner. \* marked with: Cd = cadmium, Hg = mercury, Pb = lead. Return your product to your collection point with the fully discharged battery installed inside!

# Made in China

Distributed by: Technaxx Deutschland GmbH & Co. KG Konrad-Zuse-Ring 16-18, 61137 Schöneck, Germany

Espresso To Go LX-060