TrendGeek[®] * User Manual Smartwatch TG-SW2HR

The manufacturer Technaxx Deutschland GmbH & Co.KG hereby declares that this device, to which this user manual belongs, complies with the essential requirements of the standards referred to the Directive **RED 2014/53/EU**. The Declaration of Conformity you find here: **www.technaxx.de/** (in bar at the bottom "Konformitätserklärung"). Before using the device the first time, read the user manual carefully.

Service phone No. for technical support: 01805 012643 (14 cent/minute from German fixed-line and 42 cent/minute from mobile networks). Free Email: **support@technaxx.de**

This device has a rechargeable battery. It must be fully charged before first use. NOTE: Charge the battery of the device every 2–3 month if it is not used!

Keep this user manual for future reference or product sharing carefully. Do the same with the original accessories for this product. In case of warranty, please contact the dealer or the store where you bought this product. **Warranty 2 years**

Enjoy your product * Share your experience and opinion on one of the well-known internet portals.

Features

Smartwatch and Fitness Tracker

Bluetooth 4.0 for Push messages
Free FunDo Pro APP: available at Google Play Store and at Apple AppStore
Smartphone-connectivity via Bluetooth: Push messages, camera remote release, music control, phone calls, phone book and call logs
Synchronization of contacts, messages, display of calls
Missed calls, alarm alerts (SMS, MMS, GMail, WeChat, Whatsapp, QQ, Facebook, Twitter etc.)
Anti-lost function: find your mobile phone with your watch and vice versa
Sleep monitoring: Record sleep and analyse sleep patterns
Bluetooth calls
Fitness function: Pedometer, calorie meter, heart rate, activity reminder and drink reminder
time display, alarm function, calendar, etc.

Technical specifications

Display	1.54" TFT-Display		
Processor	MTK2502D		
Bluetooth	Version 4.0		
BT transmitting frequency		2.4GHz	
BT max. radiated output power		2.5mW	
Power supply	Built-in rechargeable 220mAh		
	Lithium-polymer battery 3,7V		
Charging time	~1–2 hours (use the enclosed Micro USB		
	cable, a USB charging adapter)		
APP	FunDo Pro		
Supported APP	GB, DE, ES, PRT, IT, PL, NL, TR, CZ, FR,		
Languages	ARA, RU		
Weight / Dimensions	54g / 48.2 x 41.8 x 10.8mm		
Sorage temperature /	–20°C up to 45°C		
Operation temperature			
Package Contents	TrendGe	eek [®] Smartwatch TG-SW2HR,	
	Micro-USB charging cable, User Manual		
Compatibility	Android	4.3 or above & iOS 8.0 or above	

Charging

Plug the Micro-USB charging cable to the Smartwatch (1) and the other side to an USB power adapter* (*not included).

Produkt View



The watch should be charged at least 2 hours before use.

1	USB port	Load
2	Power button	On / Off, Screen On / Off, Back to the home screen
	Touchscreen	Each function (main menu) is displayed on the capacitive touchscreen

Start up & Operation

Power button / Operation

Hold down the on / off button for two seconds to turn on your Smartwatch. The Smartwatch display will light up, and the Start Screen will appear. **INFO:** If the last mobile device connected to your Smartwatch is turned on and the Bluetooth function is activated on both devices, then the Smartwatch will automatically connect with the mobile device.

Power button

- 1x short press \rightarrow turn on/off the display
- Press for 3-4 seconds → turn on/off the Smartwatch

Display

- Swipe to the right or the left \rightarrow open Menu
- Swipe up or down →next or previous menu page
- Swipe from top to bottom \rightarrow Short-cut function settings

Bluetooth connectivity and synchronization function

Turn on the Bluetooth on your Smartwatch:

Turn on your Smartwatch. Swipe several times up over the display until the setting icon appear. Tap the icon. Now tap BT settings. Turn ON power and visibility.

Activate Bluetooth on the mobile device

Now connect the mobile device with your Smartwatch. The Bluetooth name "**TG-SW2HR**" will show up.

Data Synchronization

After installing the FunDo Pro App and successfully connecting the telephone and Smartwatch via Bluetooth, you can synchronize data between the Smartwatch and the mobile device (see chapter: Install APP).

Install FunDo Pro APP on your Smartphone

Search for the application **FunDo Pro APP** in the Google Play Store or in the Apple AppStore.

Install this APP on your mobile device or scan the following QR-Code.



Connect the Smartwatch with the FunDo Pro APP

Wait until the Smartwatch is fully charged. Activate the Bluetooth of your Smartphone. Than open the APP. Confirm all requests to get the most out of the APP.

Press "Add device" under "More" and search for "**TG-SW2HR**". Choose **TG-SW2HR**" from the list and you are ready. Now the smartwatch is connected with your Smartphone and the APP.

Menu overview

After turning on your Smartwatch, swipe from left to right over the display to activate the menu. Swipe up or down to choose. Tap an icon to open the corresponding function. To leave the function swipe from right to left or push the Power button.

Phonebook

Synchronize contacts in order to see them on the Smartwatch.

Dialer

Enter the telephone number to dial from the Smartwatch.

Call logs

After connecting with the Bluetooth, you can check your call logs. Shows all records including failed calls, dialed calls, and received calls.

Messaging

Synchronize telephone messages. (only for Android)

Notifier

For SMS, incoming Skype messages and other applications on the connected telephone, the watch's telephone will notify you in order that you may read them.

Bluetooth

Turn the Bluetooth on / off and the visible feature on / off. You can check the Bluetooth name and address. Search and connect to Smartphone.

Pedometer

Keep an eye on your fitness with the pedometer. It counts your footsteps and calculates calorie consumption and distance travelled.

Sleep Monitor

If you would like to monitor your sleep quality based on your sleeping time, you should wear the Smartwatch on your wrist while you go to sleep. **Note:** Auto sleep monitoring only from 9 pm to 9 am.

Heart Rate

Tap the display of your smartwatch to start measuring your heartrate. **Note:** If you want to have a statistic of your heart rate you need to synch the every measurement with the FunDo Pro APP on your Smartphone.

Sedentary Reminder

You can set a time to remind yourself to exercise or just to make some steps.

Anti-Lost / Smartphone Search

The watch searches for the telephone or the telephone searches for the watch.

BT Music

Monitor and control music playback from the mobile phone via Bluetooth. Play music over your mobile phone's loudspeaker or using a Bluetooth-headset connected to your mobile phone.

Camera Remote

Use the telephone's camera to take photos; you can tap on the display to make a photo.

Settings

In the Smartwatch settings, you can reset time, theme, language, visual display and factory defaults.

In order to reset the Smartwatch to default, tap in Setting menu on "Reboot Settings".

Additional Smartwatch Functions


Alarm, Calendar, Stopwatch, Calculator, Siri control, Weather display, Energy Saving Mode, Counter, QR-Code for app download.

Hints

Bluetooth connection becomes disconnected when the Smartwatch exceeds a certain distance.
 Smart-search function cannot be used after the Anti-lost-function has been turned on until connection via Bluetooth has been reestablished.
 Reconnect with Bluetooth does not work for more than 5 min.
 Consent to the telephone book synchronization; otherwise you will have no telephone book synchronization.
 Titles are displayed when listening to music. This is not the case when using mobile devices.

Safety instructions

 Rebuilding or modifying the product impairs product safety. modifications and repairs of the device or accessories must be performed by the manufacturer or by persons expressly authorized by the manufacturer. • Never open the product by yourself. Never perform repairs by yourself! • Handle the product carefully. It can be damaged by knocks, blows or even by falling from low height. • Keep the product away from damp, moisture and extreme heat. • Never immerse the product in water or other fluids. • Technical specifications are subject to change without notice. • Never heat the battery above 60°C and do not drop or throw it into the fire, danger of explosion/fire hazard! • Do not short-circuit the battery. • Do not subject the battery to mechanical stress. Avoid dropping, striking, bending, twisting or cutting the battery. • Discontinue the charging process immediately should the battery become overheated. A battery that becomes overheated or deformed during the charging process is defective and should no longer be used. • Never drain the battery completely, as this shortens its lifetime. • It is essential to observe the correct polarity of the battery. An incorrectly inserted battery can result in destruction of the product, danger of fire hazard. • If the battery must be stored, it is recommended that it be stored at 30% of its loading volume. Store out of direct sunlight. Ideal storage temperature: 10–20°C. ● Keep the product away from little children.



Hints for Environment Protection: Packages materials are raw materials and can be recycled. Do not disposal old devices or batteries into the domestic Cleaning: Protect waste. the device from contamination and pollution. Avoid using rough, coarse-grained materials solvents/aggressive or cleaner. Wipe the cleaned device accurately. Distributor: Technaxx Deutschland GmbH & Co.KG, Kruppstr. 105, 60388 Frankfurt a.M., Germany