


Technaxx® user manual

Marten Repellent TX-368

with battery function

Before using the appliance for the first time, please read the instructions for use and safety information carefully.



Keep this user manual for future reference or product sharing carefully. Do the same with the original accessories for this product. In case of warranty, please contact the dealer or the store where you bought this product.

Features

- Repellent with ultrasonic and LED flash
- Battery operated with 4x AA
- With car connection cable and USB cable
- Easy to use and mount

Declaration of Conformity

The EU Declaration of Conformity of TX-368, Item No. 5388 is according to Directive 2014/30/EU and can be requested at the following address: www.technaxx.de/.

Disposal


Disposal of the packaging. Sort packaging materials by type upon disposal. Dispose cardboard and paperboard into the wastepaper. Foils should be submitted for recyclables collection.

Disposing of old equipment (Applies in the European Union and other European countries with separate collections (collection of recyclable materials) Old equipment must not be disposed of with household waste! Every consumer is required by law to dispose of old devices that can no longer be used separately from household waste, e.g. at a collection point in his or her municipality or district. This ensures that the old devices are properly recycled and that negative effects on the environment are avoided. For this reason, electrical devices are marked with the symbol shown here.

Technical specifications

Input	USB-C 5 - 12 V DC
Batteries	4x AA 1,5 V (not included)
Working time (battery)	Approx. 45 days
Frequency	12 kHz - 24 kHz
Range	20 m ² (open field)
Fuse	F1AL 250 V
Working temperature	-10 ~ +60 °C
Weight / Dimension	130 g / 127 x 65 x 30 mm
Package content	Marten Repellent TX-368, battery cable 0.6m, USB cable 1m, 2x cable tie, user manual

Product Overview



Installation

• Install the device near an entry, where martens or other small rodents can enter the area. Do not block the ultrasonic speaker and point the flash led towards the entry. • Connect the battery cables to the engine battery or use batteries to power the device. Secure the device and the cables with cable ties.

Operation

• Insert one end of the randomly delivered USB cable into a power adapter (DC5V/1-2A adapter, not attached), and the other end into the USB-C power port (1) of the device. Alternatively, connect the device to the car battery (up to 12V DC) by securely connect red wire (11) to positive terminal ("+") and black wire (12) to negative terminal ("-") of the battery; or insert 4x AA batteries into the battery compartment. • Press the on / off button (4) to activate the device. The red indicator LED and the flash LED will light up 3 times. Press and hold the power button for 5 seconds to turn it off. Note: The device turns off while the engine is running and reactivates 80 seconds after the engine shuts off.

Powder compartment

Fill the powder repellent compartment (9) with an amount of repellent (not included), ensuring it is securely closed and placed in a dry area.

CAUTION

- Do not touch both cable lugs while the device is powered – risk of electric shock!
- Ensure cables are secured and do not touch moving or hot parts. Risk of short circuit!
- Keep the device dry – do not expose it to water or other liquids.
- Do not install while the engine is running – risk of injury!
- Keep the device out of reach of children.
- Keep away from flammable or explosive materials.

Safety instructions

• Observe the safety instructions during use. • This device is for stationary operation only. Please do not use it while driving. • Disconnect the device if the vehicle will be unused for extended periods to prevent battery drain. • Installation should be performed by a qualified technician. Incorrect installation may result in electrical damage or risk of fire. • Any modification or alteration of the product will affect the safety of the product. Caution, risk of injury! • All changes and repairs to the product or its accessories may only be carried out by the manufacturer or by persons expressly authorized by the manufacturer. • Never open the product without authorization. • Never carry out repairs yourself! • Handle the product with care. It can be damaged by shaking or falling from a small height. • Never immerse the product in water or other liquids. • Technical changes and errors reserved.

Support

Service phone No. for technical support: **01805 012643**
(14 cent/minute from German fixed-line and 42 cent/minute from mobile networks). Free Email: support@technaxx.de
The support hotline is available Mon-Fri from 9 am to 1 pm & 2 pm to 5 pm.

Cleaning and maintenance

• Clean the equipment with a moist cloth. Do not use cleaning agents or solvents. • Ensure that no water can seep in. The ingress of water into an electric device increases the risk of electric shock or damage of the device.

Disclaimer

Technaxx Germany GmbH & Co KG is not responsible for any damages caused by:
• Improper installation or use of the device.
• Unauthorized modifications, repairs, or tampering.
• Damage to vehicles or injury caused by misuse or failure operation.
• Damage caused by martens, rodents, or other animals after installation.

Made in China

Distributed by:
Technaxx Deutschland GmbH & Co. KG
Konrad-Zuse-Ring 16-18,
61137 Schöneck, Germany