

Technaxx® user manual

Warning Beacon TX-395

Before using the appliance for the first time, please read the instructions for use and safety information carefully.

Keep this user manual for future reference or product sharing carefully. Do the same with the original accessories for this product. In case of warranty, please contact the dealer or the store where you bought this product.

Features

- 9V powered up to 10 h
- Bright 360° warning light
- Up to 1km visible
- Magnetic mount
- One button operation
- Small and easy to store

Declaration of Conformity



The EU Declaration of Conformity can be requested at the following address: www.technaxx.de/ (in the lower bar "Declaration of Conformity").

Disposal



Disposal of the packaging. Sort packaging materials by type upon disposal. Dispose of cardboard and paperboard in the waste paper. Foils should be submitted for recyclables collection.




Disposing of old equipment (Applies in the European Union and other European countries with separate collection (collection of recyclable materials) Old equipment must not be disposed of with household waste! Every consumer is required by law to dispose of old devices that can no longer be used separately from household waste, e.g. at a collection point in his or her municipality or district. This ensures that the old devices are properly recycled and that negative effects on the environment are avoided. For this reason, electrical devices are marked with the symbol shown here.

Technical specifications

Light source	LED
Visibility	1km / 360°
Flashing frequency	0.8 - 1 Hz
Battery	9V 6LR61
Mount	Magnetic
Operating time	Up to 10 h
Material	PC, TPE
Protection class	IP54
Working temperature	-20 – 70°C
Weight / Dimension	175 g / Ø 9 x 5 cm
Package content	TX-395, battery (9V 6LR61), user manual

Product Overview



Operation

- Battery Status Check: Short press the SOS button to display the battery status indicator for 10 seconds.
- Power On/Off: Press and hold the SOS button for 3 seconds to switch the device on or off.

Battery Indicator

The battery status is indicated by the LED color:

- **Green:** Battery level $\geq 75\%$
 - **Orange:** Battery level approximately 50%
 - **Red:** Battery level $\leq 25\%$
- Recharge or replace the battery when the red indicator is displayed.

Battery Installation / Replacement

Turn off the device before opening the battery compartment. Open the compartment according to the product design. Insert the batteries with correct polarity (+/-). Close the compartment securely before use.

Mounting Instructions

Mount the device securely on the top of the vehicle, ensuring it is stable and clearly visible from all directions. Do not cover or obstruct the light. Check that the unit is firmly fixed before each use.

WARNING

The device must not be used while driving. It is intended for use only when the vehicle is stationary.

Recommended procedure in an emergency:

- Activate your vehicle hazard warning lights.
- Put on a high-visibility vest.
- Set up a warning triangle at a safe distance.
- Use this warning light as an additional safety measure.
- Leave the accident or breakdown site and get to safety.
- If necessary, contact emergency services or the police.

Note: Legal requirements are subject to change. Users are obligated to comply with all applicable national and local regulations.

CAUTION

- This device is intended as an aid and does not guarantee rescue or emergency response.
- Always contact emergency services directly when possible.
- Do not rely solely on this device for personal safety.
- Do not immerse water or other liquids.
- Keep children away from the device.
- Keep away from flammable and explosive materials.
- Do not throw in fire.

Safety instructions

•Use the product only for its intended purpose. •Do not modify, disassemble, or tamper with the device. •Use only approved batteries. •Do not expose batteries to fire, excessive heat, or direct sunlight. •Replace damaged batteries immediately. •Do not short-circuit battery terminals. •Observe the safety instructions during use. •Any modification or alteration of the product will affect the safety of the product. Caution risk of injury! •All changes and repairs to the product or its accessories may only be carried out by the manufacturer or by persons expressly authorized by the manufacturer. •Never open the product without authorization. •Never carry out repairs yourself! •Handle the product with care. It can be damaged by shaking or falling from a small height. •Never immerse the product in water or other liquids. •Technical changes and errors reserved.

Support

Service phone No. for technical support: **01805 012643** (14 cent/minute from German fixed-line and 42 cent/minute from mobile networks). Free Email: **support@technaxx.de**
The support hotline is available Mon-Fri from 9 am to 1 pm & 2 pm to 5 pm.

Cleaning and maintenance

•Clean the equipment regularly with a moist cloth. Do not use cleaning agents or solvents. •Store in a cool, dry place. •Remove batteries during long-term storage.

Made in China

Distributed by:
Technaxx Deutschland GmbH & Co. KG
Konrad-Zuse-Ring 16-18,
61137 Schöneck, Germany