


Bottle neck Lamp LU-010*011*012*013

Before using the appliance for the first time, please read the instructions for use and safety information carefully.



This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capacities, or by persons lacking in experience or knowledge, unless they are supervised or instructed on the use of this device by a person responsible for their safety. Children should be supervised to ensure they do not play with this device.

Keep this user manual for future reference or product sharing carefully. Do the same with the original accessories for this product. In case of warranty, please contact the dealer or the store where you bought this product.

Enjoy your product. * Share your experience and opinion on one of the well-known internet portals.

Specifications are subject to change without notice - please be sure to use the latest manual available on the manufacturer's website.

Table of Contents

Hints.....	2	Cleaning the product.....	5
Safety instructions	2	Technical Specifications.....	5
Warnings.....	3	Support	6
Disclaimer	4	Care and maintenance.....	6
Battery Charging	4	Declaration of Conformity.....	6
Package content	5	Disposal.....	6
Maintenance.....	5		

Hints

● Only use the product for purposes due to its intended function ● Do not damage the product. Following cases may damage the product: Incorrect voltage, accidents (including liquid or moisture), misuse or abuse of the product, faulty or improper installation, mains supply problems including power spikes or lightning damage, tampering or modification of the product by persons other than authorized service personnel, exposure to abnormally corrosive materials, insertion of foreign objects into the unit, used with accessories not preapproved. ● Refer to and heed all warnings and precautions in the user manual.

Safety instructions

- This product is not a Toy. Keep it away from children and pets.
- Do not leave packaging materials lying around carelessly.
- These could become a dangerous Toy for children
- If you have any questions which couldn't be answered by this document, please contact our technical customer service or other specialist staff
- Have maintenance, adjustment, and repair work carried out exclusively by a specialist or a specialist workshop.
- Be careful with the product. Impacts, blows, or falling from a low height can damage the product.
- Do not subject the product to mechanical stress.
- Protect the product from extreme temperatures, strong impacts, flammable gases, vapors and solvents.
- Protect the product from high humidity and moisture
- Protect the product from direct sunlight
- If you have any doubts about the operation, safety, or connection of the product, consult a specialist.
- If safe operation is no longer possible, take the product out of service and protect it from unintentional use. DO NOT attempt to repair the product yourself. Safe operation is no longer guaranteed if the product:
 - shows visible damage,

- no longer functions properly,
- has been stored for a long period of time under unfavorable environmental conditions, or
- has been subjected to significant transport stress.
- The battery is permanently installed in the product and cannot be replaced ● Never damage the battery
- Damage to the battery casing may result in explosion and fire ● The battery contacts/connections must not be short-circuited ● Do not throw the battery or the product into a fire ● There's a risk of explosion and fire
- Charge the battery regularly even when the product is not in use. The battery technology used allows charging without prior discharge ● Never leave the product's battery unattended while charging ● Place the product on a heat-resistant surface while charging. Some warming during the charging process is normal ● Do not look directly into the light ● Do not look directly into the light beam or view it with optical instruments ● Never touch the product with wet or damp hands. ● The product can only be operated with the voltage described on the interior panel. ● Do not place the product on an unstable surface. The unit could be damaged or persons could be injured. Any attachments should be made only in accordance with the manufacturer's instructions or obtained from the manufacturer. ● The cable is sheathed and insulates the current. Do not place any objects on the cable, as this could cause the protective function to be lost. Avoid placing excessive stress on the cable, especially at sockets and plugs.
- If you want to pull the plug out of the socket, always pull on the plug and not on the cable. The cable could otherwise break. ● Do not overload wall outlets, extension cords, or other wiring as this may result in fire or electric shock. ● Do not insert any objects into the openings of the unit, as current flows in some places and contact may cause fire or electric shock.
- Unplug the power cord from the power outlet for cleaning. ● Do not use liquid cleaners or cleaning sprays. The product may only be cleaned with a damp cloth. ● Keep the product away from open fire, soldering irons, or other hot tools as this could damage the product.
- Never use the product outdoors. The product is intended for indoor use only.

Warnings

- Do not disassemble the product, it may result in short-circuit or damage.
- Do not modify, repair or remove without professional guidance. ● Do not use corrosive or volatile liquid for cleaning. ● Do not drop or shake the device, it may break internal circuit boards or mechanics. ● Keep the device away from little children.

Disclaimer


● In no event shall Technaxx Deutschland be liable for any direct, indirect punitive, incidental, special consequential danger, to property or life, improper storage, whatsoever arising out of or connected with the use or misuse of their products.

Battery Charging

- Connect one end of the cable to a suitable power source and the other end to the product's 5V DC 1A charging input
- The charging status is indicated as follows: Red (charging), Green (fully charged).

How to use

- Press the on/off button to turn the product on and off or change light colour.
- Hold the on/off button to increase or decrease the brightness
- To switch the light-color press the power button 1 time, 3 light colors available

	1	Bottleholder
	2	On/Off/ color change/ dimm
	3	USB charging port

Package content

LU-010/011/012/013

1x MainUnit
1 x USB charging cable
1x Bottle holder
1x User Manual

Maintenance

Cleaning the product

The MainUnit can be cleaned.

To clean the product:

Use a dry, lint-free cloth to clean the product

Wipe with damp cloth if needed. CAUTION! Keep water out of the MainUnit.

If any parts break, replace them. CAUTION! Do not open, modify, or repair the product.

Do not use aggressive cleaning agents, rubbing alcohol, or other chemical solvents. This may damage the housing and cause the product to malfunction. Do not immerse the product in water.

Technical Specifications

Power	1,5 W
charging	Via USB-C cable
Battery	3.7 V, 1800 mAh, Li-ion battery, type 18650
Working time	4-5 hour
Weight	0.20kg
Dimension (LxWxH)	11 x 12 x 8.5cm
Brightness	200 lm max.
LEDs	44
Light colors	Warm-white, cold-white, yellow 3000-6000k
Dimming	stepless
IP	IP44
Bottle neck diameter (outer)	max. Ø30mm

Support

Service phone No. for technical support: **01805 012643** (14 cent/minute from German fixed-line and 42 cent/minute from mobile networks). Free

Email: **support@technaxx.de**

The support hotline is available Mon-Fri from 9am to 1pm & 2pm to 5pm

Care and maintenance

Clean the device only with a dry or slightly damp, lint-free cloth.

Do not use abrasive cleaners to clean the device.

This device is a high-precision optical instrument, so in order to avoid damage, please avoid the following practice:

- Use the device in ultra-high or ultra-low temperature.
- Deliver or use it in strongly shocking environment.

Declaration of Conformity



The EU Declaration of Conformity can be requested at the following address: www.technaxx.de/ (in the lower bar "Declaration of Conformity").

Disposal



Disposal of the packaging. Sort packaging materials by type upon disposal.

Dispose of cardboard and paperboard in the waste paper. Foils should be submitted for recyclables collection.



Disposing of old equipment (Applies in the European Union and other European countries with separate collection (collection of recyclable materials) Old equipment must not be disposed of with household waste! Every consumer is required by law to dispose of old devices that can no longer be used separately from household waste, e.g. at a collection point in his or her municipality or district. This ensures that the old devices are properly recycled and that negative effects on the environment are avoided. For this reason, electrical devices are marked with the symbol shown here.



Batteries and rechargeable batteries must not be disposed of in household waste! As a consumer, you are required by law to dispose of all batteries and rechargeable batteries, whether they contain harmful substances* or not, at a collection point in your community/city or with a retailer, to ensure that the batteries can be disposed of in an environmentally friendly manner. * marked with: Cd = cadmium, Hg = mercury, Pb = lead. Return your product to your collection point with the fully discharged battery installed inside!

Made in China

Distributed by:

Technaxx Deutschland GmbH & Co. KG
Konrad-Zuse-Ring 16-18,
61137 Schöneck, Germany

Luminaxx Bottleneck Lamp LU-010/011/012/013