Lifenaxx® * User Manual

Lifenaxx Pet Care Set LX-052

Before using the appliance for the first time, please read the instructions for use and safety information carefully.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capacities, or by persons lacking in experience or knowledge, unless they are supervised or instructed on the use of this device by a person responsible for their safety. Children should be supervised to ensure they do not play with this device.

Keep this user manual for future reference or product sharing carefully. Do the same with the original accessories for this product. In case of warranty, please contact the dealer or the store where you bought this product.

Enjoy your product * Share your experience and opinion on one of the well-known internet portals.

Specifications are subject to change without notice - please be sure to use the latest manual available on the manufacturer's website.


Features


- Multifunctional care tools
- Hair trim and suction in one step
- Large container capacity
- Strong vacuum power
- Lightweight and compact
- With HEPA filter

Technical specifications

Input	220 V ~ 50 Hz			
Power	350 W			
Mode	3 Suction levels (<12000Pa)			
Container capacity	1.5 L			
Hose length	1.6 m			
Wire length	2 m			
Decibel	<75 dB			
Product size	28.5 x 12 x 17.8 cm			
Product weight	2.7 kg			
Package content	Vacuum unit, flexible hose, grooming brush, clipper, deshedding brush, massage brush, 2-in-1 flat brush, roller brush, 6 clipper guide combs, cleaning brush, lubricant, accessories holder, accessories bag			

Product overview







1	Vacuum device	2	Grooming brush
3	Deshedding tool	4	Massage brush
5	Pet hair roller brush	6	2-in-1 Flat brush
7	Clipper	8	Hose
9	6x Guide comb (24 mm, 18 mm, 12 mm, 9 mm, 6 mm, 3 mm)		

Vacuum device

- (45) Mode adjustment
- Mode indicator
- On/Off button
- © Container release button



Installation




Put the dust container along the direction of the arrow in the figures.


Push to lock the hose on the machine.


To release the hose, push the lock button down.

Note: The hose has a power wire included. This is only necessary for the clipper adapter.




Install an adapter to the hose






Usage of adapter



Grooming brush



Press the button to lock the comb. Clean floating hair and dust from your pet's fur. Comb the pet's hair to make it fluffy and shiny.

To lose the hair, press the button again and the hair will be sucked in.

Deshedding tool

Remove loose hair quickly and comfortable. **Note:** Be careful of the sharp edge of the deshedding tool to avoid scratching the skin through excessive force.



Pet hair roller brush




Use this brush to remove hair from clothes, sofas and carpets.

Move the brush back and forth. It will pick up loose hairs and suck them in. To service the brush, open the transparent cover and clean it.


2-in-1 Flat brush

Suck in all loose hair on textiles or floors. Use the flip-brush to clean details in small spaces like seams and joints.



Clipper

This product effectively shaves your pet's hair and prevents hair from being dispersed or inhaled. The grooming process leaves no residue and prevents loose hairs from flying around the room.




Slide the power switch to turn the clipper on and off. The clipper only works when the vacuum is switched on.

Note: Please take extra care when using the product on soft parts of your pet's skin and avoid using excessive force as this may cause cuts or injury.


Massage brush

Use the massager in a gentle, circular motion around your pet's sweet spots. The vacuum sucks up any loose fur particles.

Pet massages get the blood circulation flowing and boosts the pet's metabolism.



Care and maintenance Clean the dust container



Press the dust container release button (a) and detach the bin from the vacuum unit.

Open the dust container by gently bend the holder clip. Remove all lose particles.

Reinstall the dust bin by put it back onto lock the vacuum unit until the mechanism is hearable.

Clean the clipper

Detach the blade unit by hold the clipper and push with your thumb towards the blade and remove it from the clipper.

Use the small cleaning brush (attached) to clean the blade unit from small hair particles.


Put a few drops of the lubricant (attached) on the blades of the scissor unit.

Align the bottom of the blade unit in place and press it down to reinstall to the clipper unit. It should fit nice and even to the clipper unit.

Clean the HEPA filter

Please clean the HEPA filter every six months. To do so, detach the dust container and remove the filter carefully. After cleaning, the HEPA filter should be dust-free.

Use compressed air or gently shake the dust off. Keep the original HEPA filter in use.



Do the same with the pre-filter sponge. Rinse it under running water to clean it. Let it dry for 24h and reuse the sponge at the dust container.

Note: This routine can vary depending on use frequency. Only use a dry sponge filter. If it is dirty, clean it.

Care

Clean the device only with a dry or slightly damp, lint-free cloth. Do not use abrasive cleaners to clean the device.

Support

Service phone No. for technical support: **01805 012643*** (14 cent/minute from German fixed-line and 42 cent/minute from mobile networks). Free Email: **support@technaxx.de**

The support hotline is available Mon-Fri from 9am to 1pm & 2pm to 5pm In case of accidents with this product, please write to: **gpsr@technaxx.de**

Notes

•Pets may be afraid of or resistant to the vacuum cleaner the first time it is used. Please set the unit to "mute" at the beginning to allow the pets to get used to it for about two weeks. "Mute" means that the vacuum function

is not activated. •If the device has a strange smell when you first use it, don't worry. It's normal and safe. •If you smell something burning, stop using the product right away. •Keep the dust container and filter clean. If they're dirty, there might be malfunctions or accidents. •Before you do any maintenance, make sure to cut the power and unplug the cord. •Avoid kinking or squeezing of the hose. •If the device power turns on during maintenance, there is a risk of electric shock, accidents, or injuries. •The device has overheating protection. If the motor temperature rises abnormally or the air inlets are blocked, the device will stop automatically. •If this happens, remove the dust container and clean the air inlets or filter. Then wait for 60 minutes before turning the device back on. •Please make sure the filter is installed correctly. If the filter is removed or installed incorrectly, it could cause malfunctions.

Troubleshooting

- LX-052 does not turn on: Check the connections; the plug is not inserted correctly. The vacuum is in a state of overheating protection. Check the air inlets for any blockage. Reinstall HEPA filter and wait 60 minutes.
- Weak suction: Clean the hose and the parts of the air inlet. Empty the dust container. Clean the sponge filter and HEPA. The HEPA is not dry enough after washing.
- The pet does not cooperate: Set the vacuum to "mute" state. You can use treats to make your pet feel more comfortable.

Warnings

•This product is only for household use. It is not for commercial or industrial use, or for use in outdoor or humid places. •When using this vacuum cleaner, keep an eye on children. •This vacuum cleaner is not for people (including children) who have physical, sensory, or mental limitations, or who do not have experience or knowledge about using the vacuum cleaner. This is unless they have been given supervision or instruction about using the vacuum cleaner by the person responsible for their safety. •Keep the device away from children and use it with full attention toward pets. •Do not touch the power plug or the product with wet hands. •Do not use the vacuum cleaner on wet hair or liquids. •Do not use this product when the power cord or power plug is damaged. •Do not use the product when it cannot work correctly or when it is damaged, when it is outdoors, or immersed in liquid. •Do not take the product apart. If you do, you could get an electric shock or a fire. •Do not breathe in flammable or combustible liquids and gases in the vacuum cleaner. And do not use the vacuum cleaner in or near the environment with flammable and combustible gases. •Do not pull the power cord, put heavy stuff on the top of the machine. •Do not smoke, use matches, or put things that can catch on fire near the vacuum cleaner. •Do not put things into the device opening or block the device opening for use. •When changing the device parts, or maintaining the device after using it several times, please pull the power cord out. •Do not use the device with fragrance or put fragrance in the filter part. The fragrance could cause a fire.

Declaration of Conformity



The EU Declaration of Conformity for 5273 / LX-052 can be requested at the following address: www.technaxx.de/ (in the lower bar "Declaration of Conformity").

Disposal



Disposal of the packaging. Sort packaging materials by type upon disposal.

Dispose of cardboard and paperboard in the waste paper. Foils should be submitted for recyclables collection.

Made in China

Distributed by: Technaxx Deutschland GmbH & Co. KG Konrad-Zuse-Ring 16-18, 61137 Schöneck, Germany