

Technaxx® User Manual

Electronic Mini Parking Disc TX-353

Please read the instructions for use and the safety information carefully before using the device for the first time.

No liability is assumed for fines, tickets or other legal consequences resulting from improper use or non-compliance with local parking regulations.

Please keep this manual carefully for future reference or for sharing this product. Please do the same with the original accessories for this product. In the event of a warranty claim, please contact the retailer or store where you purchased this product.

Features

- Motion sensor
- Automatically sets the parking time
- Magnet adhesive
- KBA-Licensed

Technical specifications


KBA license no.	E1 10 R - 0610668
Parking detection response time	Approx. 60 seconds
Accuracy of the time	±2min. / year
Parking time interval	0 minutes / 15 minutes / 30 minutes (adjustable)
battery	3V button cell CR2450 (included in delivery)
Battery life	Approx. 1 year
material	ABS + PC
Operating temperature	-20°C – 75°C
Weight of the device	40 g
Dimensions of the device	(L) 6 x (W) 6 x (H) 1.8 cm
Packaging contents	Electronic Mini Parking Disc TX-353, CR2450 battery, user manual

IMPORTANT

The TX-353 electronic parking disc must not be placed loosely in the vehicle. To be legally recognized, it must be attached to the lower right side of the windshield.

After approximately 60 seconds of inactivity, the parking disc will show the parking time on the front display (marked with "Ankunftszeit").

Product overview



Functions



Assembly instructions

Make sure the parking disc is clearly visible and attached to the windshield. The temperature during installation should be at least +15°C; otherwise, a secure hold cannot be guaranteed.

- Make sure the area you want to use is clean and dry.
- Do not use cleaning products that contain alcohol.
- Peel off the red protective film from the pads.
- Press firmly for at least 20 seconds.

Setting the time

To activate the setting mode, press and hold button 3 until the "hour" digits flash on the display (1).

- Press button 2 or 4 to set the time until the hours match the current time.
- Press button 3 again to switch to the minutes.
- The "minute" digits flash. Set the minutes using button 2 or 4.
- Follow the same steps to set the current date.

Note: After 15 seconds without any input, the time setting will automatically exit. After that, you must press and hold button 3 again to activate it.

Battery replacement

Please change the battery as soon as the LED light (5) starts to light up. Pull out the battery compartment (6) and carefully pull out the battery.

Replace the CR2450 battery with a new, unused battery. Insert the battery into the compartment with the positive pole facing up. Carefully slide the battery compartment back into the device.

Note: The time and date may need to be reset.

Set summer and winter time

By default, the parking disc is set to automatically switch between daylight saving time and wintertime. For countries without daylight saving time, this function can be deactivated as follows:

- Press buttons 2 and 3 for 3 seconds.
- Display 1 shows "ON:SU." Automatic daylight-saving time is activated.
- To deactivate the automatic time change, press button 2.
- Display 1 shows "OF:SU".

Changing the time interval

Different countries may have different requirements for parking time. Change the interval to 0, 15, or 30 minutes depending on the parking regulations in that country.

- Press and hold button 2 and 4 and press 4 again to switch between 00, 15 or 30 minutes.

Note: 30 minutes is set as the default.

Cleaning and maintenance

- Clean the device regularly with a damp cloth. Do not use cleaning agents or solvents.
- Ensure that no water can penetrate the device.
- Protect the device from shocks, dust, moisture, or extreme temperatures.

Safety instructions



Caution! Device contains a battery.

- Keep the device out of reach of children.
- Follow the safety instructions during use.
- Never attempt to open the device, as doing so will void any warranty or guarantee for the product.
- Do not use the device if the battery compartment does not close securely.

Support

Technical support telephone number: **01805 012643**

(14 cents/minute from German landlines and 42 cents/minute from mobile networks).

Toll-free email: **support@technaxx.de**

The support hotline is available Monday to Friday from 9 a.m. to 1 p.m. and 2 p.m. to 5 p.m.

Declaration of conformity



This product is approved by the German Federal Motor Transport Authority under license number E1 10 R - 0610668. The approval can be requested at the following address: www.technaxx.de/ (search for "Declaration of Conformity" in the lower bar) and article number 5345.

Disposal



Disposal of packaging. Sort packaging materials according to their intended disposal method. Dispose of cardboard and paper with the waste paper. Films should be disposed of at the recycling center.



Disposal of old devices (Applies in the European Union and other European countries with separate collection (collection of recyclable materials) Old devices must not be disposed of with household waste! Every consumer is legally obliged to dispose of old devices that can no longer be separated from household waste, e.g. at a collection point in their municipality or district. This ensures that the old devices are recycled properly and negative impacts on the environment are avoided. For this reason, electrical devices are marked with the symbol shown.



Batteries and rechargeable batteries must not be disposed of with household waste! As a consumer, you are legally obliged to dispose of all batteries and rechargeable batteries, regardless of whether they contain harmful substances* or not, at a collection point in your community/city or at a retailer to ensure that the batteries can be disposed of in an environmentally friendly manner. * Marked with: Cd = Cadmium, Hg = Mercury, Pb = Lead. Return your product with the fully discharged battery to your collection point!

Made in China

Distributed by:
Technaxx Deutschland GmbH & Co. KG
Konrad-Zuse-Ring 16-18,
61137 Schöneck, Germany